



| Article number: Description: | 221 918 Installation kit 1 (crane assistance) | Article number: Description: | 221 919 Installation kit 2 (crane assistance) |
|---------------------------------|--|------------------------------|--|
| Contents: | 10 cruciform brackets with holes 10 pins (ISO 2338 - 8m6x60) 20 punching screws 10 anchor blocks | Contents: | 10 cruciform brackets without holes 10 pins (ISO 2338 - 8m6x60) |

Installation kit 1 (crane assistance)

Installation kit 1 (crane assistance) is a quick install system for pre-assembling an array of standard PV modules and for fitting them in PV Light mounting rails with the help of a crane.

Features

- Quick and easy assembly
- Can be pre-assembled
- Weather-resistant aluminium
- Proof of structural integrity

Installation kit 2 (crane assistance)

Installation kit 2 (crane assistance) is a quick install system for pre-assembling an array of standard PV modules and for fitting them in PV Light mounting rails with the help of a crane. It supplements installation kit 1 (crane assistance) as a centre piece that does not need to be screwed.

Features

- Quick and easy assembly
- Can be pre-assembled
- Weather-resistant aluminium
- Proof of structural integrity

Aluminium_{Natural}: Plate finish (similar to RAL 7035, light grey)

Aluminium_{Natural}: Plate finish (similar to RAL 7035, light grey)